
Design your own

Embedded Linux Control Centre

on PC and Raspberry Pi



Hans Henrik Skovgaard



an Elektor Publication

LEARN | DESIGN | SHARE

Contents

List of figures/images	13
List of tables	23
1. Introduction	25
1.1. Why this book?	25
1.2. Who is this book designed for?	26
1.3. How to use this book?	27
1.4. Organisation of the book	28
1.4.1. Section 2: Preparations for installing the control centre	28
1.4.2. Section 3: DSL: Installing and configuring the control centre	28
1.4.3. Section 4: Debian: installing and configuring the control centre on a Raspberry PI .	29
1.4.4. Section 5: Lubuntu: installing and configuring the control centre.	29
1.4.5. Section 6: Add-ons to the control centre.	29
1.4.6. Section 7: Operating the control centre	29
1.4.7. Section 8: Useful information	29
1.4.8. Section 9: Source code walkthrough	29
1.4.9. Section 10: Troubleshooting	30
1.5. Abbreviations	30
1.6. Changes since the last edition of this book	30
1.7. References	31
1.7.1. Links	34
1.8. More about links	36
2. Preparations for Installing the Control Centre	37
2.1. Choosing the correct version of Linux	37
2.2. DSL Linux for old hardware (Pentium II 300 MHz)	37
2.3. Debian for Raspberry PI	37
2.4. Lubuntu for newer hardware	37
2.5. Hardware attached to the control centre	38
3. DSL: Installing and configuring the control centre	41
3.1. DSL: Linux Operating System	42

3.1.1. Install and configure DSL	49
3.2. DSL: Web server related software	57
3.2.1 XAMPP.	57
3.2.2. Configure XAMPP	60
3.2.3. XAMPP development package	63
3.3. DSL: Compiler software.	65
3.3.1. GCC compiler installation	65
3.3.2. USB library installation	68
3.4. DSL: Basic installation and configuration of the control centre	73
3.4.1. Introduction	73
3.4.2. Web interface	73
3.5. DSL: Connecting to the ELCC	77
4. Debian: Installing and Configuring the Control Centre on a Raspberry PI.	87
4.1. Debian: Linux Operating System	88
4.1.1. Installing Raspbian	88
4.1.2. Remote connect to the Raspberry PI (or any Linux machine)	91
4.1.2.1. Install and configure Xming	91
4.1.2.2. Install and configure Windows Remote Desktop	97
4.1.3. Configure Raspbian	101
4.2. Debian: Web Server Related Software.	105
4.2.1. Apache installation.	106
4.2.2. MySQL installation.	108
4.2.3. PHP installation	110
4.2.4. Configure Apache, PHP and MySQL	115
4.3. Debian: Compiler software	116
4.3.1. MySQL libraries	117
4.3.2. USB library installation	117
4.4. Debian: Basic Installation and Configuration of the Control Centre	124
4.4.1. Introduction	124
4.4.2. Web interface installation	124
5. Lubuntu: Installing and configuring the control centre	129

5.1. Ubuntu: Linux Operating System	129
5.1.1 Install and configure Ubuntu	129
5.2. Ubuntu: Web Server Related Software	136
5.2.1. Apache installation.	136
5.2.2 MySQL installation	139
5.2.3. PHP Installation	140
5.3. Ubuntu: Compiler software.	145
5.3.1.USB lib installation	145
5.4. Ubuntu: Basic installation and configuration of the control centre	146
6. Add-ons to the control centre.	147
6.1. In/out-put interfaces.	147
6.1.1. Parallel port	147
6.1.1.1. Simple debug interface	149
6.1.1.1.2. Finding the parallel port address	150
6.1.1.3. Controlling the parallel port	151
6.1.1.4. Parallel port driver	152
6.1.2. Arduino interface (USB interface)	154
6.1.2.1. Arduino hardware interface	154
6.1.2.2. Arduino software interface	156
6.1.2.3. Arduino On/Off command line software	165
6.1.3. Raspberry PI I/O interface	166
6.1.3.1. Simple debug interface.	171
6.1.3.2. Raspberry PI I/O software driver interface	172
6.1.3.3. Raspberry PI On/Off command line software	176
6.1.4. I/O test web interface	177
6.1.4.1. Arduino On/Off Test Web Interface	179
6.1.4.2. Raspberry Pi On/Off test Web interface	181
6.1.4.3. Old parallel on/off test web interface.	182
6.1.5. Practical Use of I/O-Interface (Wireless control of 230 Volt devices).	184
6.1.5.1. Parallel port key press software	187
6.1.5.2. Debian key press software	189

- 6.1.6. I/O-interface buffer 190
- 6.2. Wake-On-LAN support. 193
 - 6.2.1. PCI versions 193
 - 6.2.2. How WOL works 199
 - 6.2.3. Remote Power up of the PC. 202
 - 6.2.4. Wake-On-LAN savings 204
 - 6.2.5. Wake On Lan from the Internet 204
 - 6.2.6. Raspberry Pi and Wake-On-LAN. 208
- 6.3. Temperature sensor 208
 - 6.3.1. The Elektor Thermo-Snake 209
 - 6.3.1.2. measuretemp 212
 - 6.3.2. DS18B20 connected to the Raspberry PI 213
 - 6.3.3. More about the DS18B20 sensor 219
- 6.4. E-mail notifications 219
 - 6.4.1. E-mail on the DSL platform. 219
 - 6.4.2. E-mail on the Debian platform (Raspberry PI). 227
 - 6.4.3. E-mail on the Lubuntu platform 229
- 6.5. SMS notifications 229
 - 6.5.1. Connecting a phone to the ELCC 230
 - 6.5.2. Connecting a data-dongle to the ELCC 237
 - 6.5.3. Installing SMS gateway software 245
 - 6.5.3.1. gnokii installed on DSL 245
 - 6.5.3.2. gnokii Installed on Raspberry PI/Lubuntu. 254
 - 6.5.4. Testing the SMS software via web interface 260
 - 6.5.4.1. Testing gnokii installed on DSL 260
 - 6.5.4.2. Testing gnokii Installed on Raspberry Pi/Lubuntu 262
- 6.6. USB webcam support on DSL. 265
 - 6.6.1. Background. 265
 - 6.6.2. Webcam Utilities and Debug tools 267
 - 6.6.3. Webcam installation and verification 272
 - 6.6.4. Live pictures on the Internet from the ELCC 275

6.6.4.1. Still pictures with spccat.	276
6.6.4.2. Streaming Pictures With spcaserv and spcaview	282
6.6.4.3. Panning the Webcam.	286
6.7. USB Webcam Support on Debian/Lubuntu	292
6.7.1. Obtaining the required software for mjpg_streamer.	293
6.7.2. Compile and Install mjpg_streamer.	296
6.7.3. Discover Webcam resolution	299
6.7.4. Add www-data to the video-group	300
6.8. Background tasks.	301
6.8.1. Cron a time-based scheduling service	301
6.8.2. Temperature update.	305
6.8.3. Alarm handling	306
6.8.4. Lamp update.	308
6.9. Additional extensions	309
7. Operating the control centre	311
7.1. Logging in to the ELCC	311
7.2. Daily operation.	312
7.2.1. System setup	313
7.2.1.1. User Management Interface	313
7.2.1.2. Language management interface	315
7.2.1.3. Video setup interface.	315
7.2.1.4. Temperature Node Management Interface	318
7.2.1.5. Lamp Setup Interface	320
7.2.1.6. Tools	321
7.2.1.7. Log Monitoring Interface	322
7.2.2. Operation	323
7.2.2.1. Video interface	323
7.2.2.2. Temperature Monitoring Interface.	324
7.2.2.3. Lamps Control Interface	325
7.2.2.4. Tools	326
7.2.3. Exit	330

7.2.4. Power Off Interface	330
8. Useful information	333
8.1. Background and some thoughts on DSL	333
8.2. First time with Linux	335
8.2.1. First time with DSL	335
8.2.2. First time with Raspberry PI or Lubuntu	338
8.3. Some useful shell commands	340
8.8. Configuring the desktop	345
8.4.1. Configuring DSL	345
8.4.1.1. Desktop	345
8.4.1.2. Fluxbox menu configuration	346
8.4.1.3. JWM menu configuration	347
8.4.1.4. The Windows Manager IceWM	348
8.4.2. Configuring Raspberry PI and Lubuntu	354
8.5. Further configuration of XAMPP (DSL installation).	354
8.6. Hiding your installation from the outside world.	355
8.7. Useful Parallel Port Data in One Place	359
8.7.1. HARDWARE interface schematic	361
8.7.2. PCB layout	361
8.8. Reverse engineering of Thermo-Snake software interface	363
9. Source code walkthrough	373
9.1. C-source code description	373
9.1.1 lptout.c	373
9.1.2. step.c	374
9.1.3. findsensor.c	375
9.1.4. measuretemp.c	377
9.1.5. temp_read_background.c	381
9.1.6. blinkOnce.c	383
9.1.7. lptout_blinkOnce.c	383
9.1.8. setPin.c	385
9.1.9.ArduinoConnectDriver.c	386

9.1.10. arduinoOnOff.c	386
9.2. Web Server Software Description	387
9.2.1. Overall description	387
9.2.1.1. MySQL Database.	387
9.2.1.2. ELCC db. installation	395
9.2.1.3. C / PHP / HTML - code	396
9.2.1.4. Language configuration	402
9.2.1.5. Web interface Config Files	403
9.2.1.6. Logging	405
9.2.2. Software description	406
9.2.2.1. send_alarm.php	406
9.2.2.2. update_lamp_status.php	408
9.2.2.3. index.php and login_form.inc.php	409
9.2.2.4. locate.php	410
9.2.2.5. PC: control.php and control_inc.php	410
9.2.2.6. pc: lamp.php and lamp.inc.php.	412
9.2.2.7. pc: statusinformation.php	413
9.2.2.8. pc: powerdown.php, powerdown.inc.php and shuttingdown.inc.php	413
9.2.2.9. pc: temp.php and temp.inc.php	414
9.2.2.10. pc: videostreaming.php and videostreaming.inc.php	415
9.2.2.11. pc:picturestreaming.php and picturestreaming.inc.php	416
9.2.2.13. pc: pictureupdate.php and pictureupdate.inc.php	417
9.2.2.13 admin: language.php and language.inc.php.	419
9.2.2.14 admin: node.php and node.inc.php	420
9.2.2.15. admin: monlog.php and monlog.inc.php	422
9.2.2.16. admin: usermgmt.php and usermgmt_form.inc.php	423
9.2.2.17. admin: lamp_setup.php and lamp_setup.inc.php	423
9.2.2.18. admin: tools.php and tools.inc.php	424
9.2.2.19. admin: video.php and video.inc.php	425
9.2.2.20. test: step_test.php and step_test.inc.php	425
9.2.2.21. test: db1820_test.php	426

9.2.2.22. test: email_test.php and email_test.inc.php	427
9.2.2.23. test: lamp_par_test.php and lamp_par_test.inc.php	428
9.2.2.24. test: lamp_test.php and lamp_test.inc.php	429
9.2.2.25. test: sms_test_d.php and sms_test_d.inc.php	430
9.2.2.26. test: sms_test_f.php and sms_test_f.inc.php	432
9.2.2.27. test: thermo_test.php	434
9.2.2.28. test: picture_test.php	434
9.3. Other software description.	434
9.3.1. Arduino I/O USB interface software	434
9.3.2. savesms.sh	435
10. Troubleshooting	437
10.1. Hardware Issues.	437
10.1.1. PC Issues	437
10.1.2. Network issues	440
10.1.3. Connecting Devices To The Raspberry Pi USB port	440
10.1.4. Arduino I/O board	441
10.2. Software issues	441
10.2.1. Operation System issues.	441
10.2.2. Compiler Issues.	445
10.2.3. Web Issues	446
10.2.4. SMS issues	446
Index	447